
OCULUS | BIOM® 5



CONDITIONING INSTRUCTIONS

BIOM® 5 and Accessories





Notes on this Instruction Manual

This instruction manual explains how to condition the BIOM® 5. It is valid for all re-usable components and accessories of the BIOM® 5 that must be sterile for use.

To ensure safe operation, it is essential that you use the device correctly. For this reason, you should thoroughly familiarize yourself with the contents of this instruction manual before operating the device. In particular, pay attention to the safety instructions.

This instruction manual describes how to condition the following BIOM® 5 models:

- BIOM 5c and 5cl (long version)
- BIOM 5m and 5ml (long version)

Due to ongoing development, the diagrams shown in the instruction manual may depict minor changes to the devices delivered.

If you have any questions or would like additional information about your device, please do not hesitate to contact us by phone, mail or fax. Our service team will gladly assist.

OCULUS Optikgeräte GmbH

Release: 22.07.2024

Revision: 02

Item Number: G/55185/EN



Table of Contents

| 1 | Appl | icability | | 1 | | |
|----|--|-----------|--|----|--|--|
| 2 | | - | ctions | | | |
| | 2.1 | About | this Manual | 1 | | |
| | | 2.1.1 | Used Graphic Symbols | | | |
| | 2.2 | Safety | Instructions for Use | | | |
| 3 | Conc | litioning | g Procedure | 4 | | |
| 4 | Com | ponents | s of the BIOM® 5 to be Conditioned | 5 | | |
| 5 | | | d Disinfection | | | |
| | 5.1 | Prepar | ation: Dismantle the BIOM® 5 | 6 | | |
| | 5.2 | - | eaning | | | |
| | 5.3 | Cleanir | ng/Disinfection by Machine | 9 | | |
| | | 5.3.1 | Information About Cleaning/Disinfection by Machine | 9 | | |
| | | 5.3.2 | Cleaning and Disinfecting by Machine | 10 | | |
| | 5.4 | Manua | ll Cleaning/Disinfection | 13 | | |
| | 5.5 | Cleanir | ng in an Ultrasonic Bath (Optional) | 14 | | |
| 6 | Stear | n Sterili | sation | 15 | | |
| | 6.1 | Prior to | o Steam Sterilisation | 15 | | |
| | | 6.1.1 | Function Check Prior to Steam Sterilisation | 15 | | |
| | | 6.1.2 | Lubrication | 18 | | |
| | | 6.1.3 | Packaging | 19 | | |
| | 6.2 | Steam | Sterilisation | 19 | | |
| 7 | Stora | ge | | 20 | | |
| 8 | Dispo | osal | | 20 | | |
| 9 | Guar | antee ai | nd Service | 20 | | |
| | 9.1 | Manuf | acturer and Service Address | 21 | | |
| 10 | Over | view: Pe | ermitted Sterilisation Method – List of Articles | 22 | | |
| 11 | Consumables and Sterilisable Accessories | | | | | |
| 12 | 27. Appendix | | | | | |





1 Applicability

These conditioning instructions explain how to condition the BIOM® 5. They apply for all models and accessories of the BIOM® 5. A list of exactly which these are is given in *sect. 7*, *page 23*.

2 Safety Instructions

- Carefully read through the conditioning instructions.
- → Keep the conditioning instructions in a safe place. You must have access to these during the conditioning process.
- → Observe the legal requirements for accident prevention.
- → Heed the supplementary conditioning information supplied with certain products.

The current version of this manual can be downloaded at www.oculus.de, or you can request a copy from OCULUS Optikgeräte GmbH, Wetzlar.

2.1 Used Graphic Symbols

2.1.1 In this Manual



Attention

Denotes a potentially hazardous situation which can easily result in minor physical injury or property damage.



Note

Denotes situations which could result in incorrect findings, denotes user instructions and useful or other important information.




Denotes important information about the product and its use, which require special attention.



2.2 On the Device

Example: Symbols on the BIOM® 5 sterilisation insert



Company logo + manufacturer
 Name of device
 Article number
 CE marking

Fig. 2–1: Symbols on the BIOM® 5 sterilisation insert

2.3 Safety Instructions for Use



Attention

Risk of injury or material damage if the conditioning procedure is done incorrectly

Observe the following safety instructions.

Risk of personal injury or property damage due to equipment modifications that could jeopardize safety

→ The BIOM® 5 sterilisation insert must not be modified without the manufacturer's permission.

2.3.1 Information about the Conditioning Personnel

→ Ensure that the conditioning is done by duly trained personnel only, who due to their qualifications or knowledge and practical experience, can guarantee proper handling.

2.3.2 Conditioning Information



Attention

Risk of injury if the BIOM® 5 is not sterile

If the patient or his bodily fluids come into contact with the BIOM® 5, it can become contaminated, e.g. when putting it away.

→ Make sure that the BIOM® 5 is cleaned, disinfected and sterilised. Condition the BIOM® 5 before the first and every subsequent use.



- → Comply with the legal provisions in force in your country, and with the hygiene and waste disposal regulations of the hospital or clinic.
- → Condition the BIOM® 5 only after you have fully understood this instruction manual.
- → The BIOM® 5 and all sterilisable components of the BIOM® 5 must be cleaned, disinfected and sterilised prior to initial use and prior to every subsequent use. To do so, take the BIOM® 5 out of the packaging.
- → Make sure that only validated device and product-specific procedures are used for cleaning/disinfection and sterilisation and that the validated parameters are observed for each cycle.
- → Use a machine (disinfector) for cleaning/disinfection purposes. This is much more effective.

2.3.3 Notes on returning



Attention

Personal injury caused by contaminated BIOM® and components

- → Before returning the product to OCULUS: Prepare the BIOM® and sterilisable components according to this treatment instructions.
- → Send only visibly prepared OCULUS products back to OCULUS


3 Conditioning Procedure

- Cleaning/Disinfection
 - Dismount BIOM® 5
 - Pre-cleaning
 - Cleaning/disinfection by machine or
 - Manual cleaning/disinfection
- Sterilising
 - Preparation for sterilisation
 - Steam sterilisation




Components of the BIOM® 5 to be Conditioned 3.1

BIOM[®] 5c/cl



- BIOM® 5cl
- Adaptor plate
- Drive belt
- 4 Ophthalmoscopy magnifying loupe
- Fig. 3-1: Components of the BIOM® 5cl

BIOM® 5m/ml



Adaptor plate

4 Safety rod

6 Reduction lens

- 2 Housing with swivel mechanism
- 5 Front loupe

Reduction lens

Fig. 3–2: Components of the BIOM® 5ml

A list of other conditionable components and other conditioning accessories is given in sect. 8, page 27.



3.2 Preparation for Cleaning and Disinfection




Recommendation:

- → Clean or disinfect the BIOM® 5 by machine, as this is much more effective.
- → Start pre-conditioning immediately after receiving the equipment in the conditioning station.

3.2.1 Dismount BIOM[®] 5

You must dismount the BIOM® 5 before you condition it.




→ Pull the BIOM® 5 off the adaptor plate. To do so, swing out the BIOM® 5



→ Take out the reduction lens and put it down onto the soft pad.

Fig. 3–3: Dismounting the components




Pull off the front loupe and put it down onto the soft pad.



For BIOM® 5c and BIOM® 5cl only:



→ Detach the cable duct from the plug.



Take off the drive belt.




Fig. 3–4: Remove additional components of the BIOM® 5c or BIOM® 5cl

3.2.2 Pre-Cleaning

Cleaning tools

- Cold water
- Water pistol

Procedure

→ Place the BIOM® 5 in cold water for five minutes. The BIOM® 5 must be fully covered.



→ Flush the gaps, joints and cavities (the marked locations) for 15 seconds with the water pistol.




Fig. 3–5: Pre-cleaning

You can now clean the components either by machine (sect. 3.3, page 12) or manually (sect. 3.4, page 16).



3.3 Cleaning/Disinfection by Machine

3.3.1 Information About Cleaning/Disinfection by Machine

Cleaning/Disinfection Unit (CDU)

→ Make sure that the CDU meets the following criteria. It must

- have been tested for efficiency (e.g. DGHM I or FDA approval, or CE marking, in conformity with DIN EN ISO 15883-1)
- Use a tested disinfection programme (at least 5 minutes at 90°C) for thermal disinfection, as with chemical disinfection, there is a risk of disinfectant residues being left on the products.

The A_0 value=3000 must be reached.

- Use water of a quality that meets the requirements of DIN EN 285 (including demineralised water with an electrical conductivity of approx. 15μS/cm).
- Use air that meets the compressed air requirements in a hospital, for drying purposes.
- → Make sure that the detergent and the disinfectant do not react with each other.

Also see "Appendix" on page 28

Regularly inspect and service the CDU in accordance with inhouse specifications.

Detergents and Disinfectants

→ Make sure that the detergents and disinfectants meet the following criteria.

The detergent (e.g. neodisher MediClean concentration 0.5 %, Dr. Weigert, Hamburg) must:

- Be suitable for cleaning the products.
- Be compatible with the disinfectant that is used.
- Be listed with the DGHM (German Society for Hygiene and Microbiology)





Note

Risk of malfunctions and surface damage if alkaline detergents are used.

If you use alkaline detergents:

- → Properly neutralise after use in accordance with the manufacturer's specifications.
- → Check whether the chemicals that are used are compatible with the products. Alkaline detergents can attack the surfaces of the products and lead to malfunctions.

If thermal disinfection (at least 5 minutes at 90°C) is not performed, the disinfectant must:

- Be of a proven efficiency (e.g. have DGHM or FDA approval, or CE marking).
- Be compatible with the detergent that is used.
- → Always adhere to the detergent and disinfectant concentrations specified by the manufacturer.

Cleaning method

The following cleaning method was used for validation of the steam-autoclavability of the BIOM[®] optics:

See sect. 9, page 28



Use the cleaning method that meets the requirements of your national standards.

3.3.2 Procedure

- → Check whether the components have been pre-cleaned, sect. 3.2.2, page 10.
- → Place the components of the BIOM® 5 into the disinfector basket or into a sterilisation tray.
- Secure the loupes in the tray with the holders provided for that purpose. Loose loupes could get scratched.
- → To ensure that the effectiveness of the cleaning/disinfection is not impaired, make sure that the components do not touch each other.
- → Place the disinfector basket or the sterilisation tray with the components in the CDU.
 - For stackable disinfection baskets or sterilisation trays, heed the manufacturer's instructions.
- → To prevent water stains on the optics, keep the loupes and reduction lenses as vertical as possible during the cleaning process.



- → Start the cleaning programme, see *sect. 9, page 28*, e.g.:
 - 3 Minute pre-wash cycle with cold water
 - Empty
 - Clean for 5 minutes at 55°C with cleaning detergent
 - Empty
 - 3 Minute rinse cycle with cold, demineralised water
 - Empty
 - 2 Minute rinse cycle with demineralised water
 - Empty
- → At the end of the programme: Remove the disinfector basket or the sterilisation tray from the disinfector.
- → Check whether the BIOM® 5 needs to be dried with compressed air.



→ Conduct a function test before you sterilise the BIOM® 5 with steam, sect. 3.6.1, page 18.

For more information about these jobs, refer to sect. 9, page 28.



OCULUS Sterilisation Insert

You can use the specially designed sterilisation insert, OCULUS Art. No. 55185 for the BIOM® 5 and its accessories.



Fig. 3–6: Components of the BIOM® 5 on the sterilisation insert

| Dimensions of the OCULUS sterilisation insert | | | | |
|---|--------|--|--|--|
| Width | 240 mm | | | |
| Depth | 245 mm | | | |
| Height | 53 mm | | | |
| Total height, loaded | 80 mm | | | |

One adaptor plate, the BIOM® 5, one reduction lens, at least one front loupe, 2 rubber drive belts, sterile cap for the knurled screw, SDI® control knob belong together. These components can be put into the special insert and placed into a suitable sterilisation container for sterilisation in the steam autoclave.



3.4 Manual Cleaning/Disinfection

The method described below has been validated for manual cleaning/disinfection:



If you clean and disinfect your equipment manually, you must verify your procedure independently and validate it specific to the product and the method.

3.4.1 Cleaning tools

- Cleaning solution with 0.8% detergent (Cidezyme/Enzol from Johnson & Johnson)
- Water

3.4.2 Procedure



- → Perform a manual disinfection in accordance with the requirements of the VAH or the applicable standards.
- → Check that the components have no visible signs of soiling, sect. 3.2.2, page 10.
- → Place the components in the cleaning solution for 5 minutes at 40°C. The BIOM® 5 must be fully covered.
- → Rinse the components for 5 seconds under running water (static pressure 4.2 bar).



3.5 Cleaning in an Ultrasonic Bath (Optional)



Note

If the fluid in the ultrasonic bath is too dirty, the cleaning effectiveness will be impaired and there is a risk of corrosion. The criterion is a visibly dirty fluid.

- Change the cleaning solution based on the operating conditions. This must be changed regularly, at least once a day.
- → When cleaning with ultrasound, adhere to the soaking times (at least 3 minutes) and concentrations specified by the manufacturer of the cleaning additive.
- → Use the quantity of fluid specified by the manufacturer of the ultrasonic bath.
- Heed the following instructions:
 - Insert the BIOM® 5 in its unfolded state, with the swivel head of the BIOM® 5 at an angle.
 - The loupe holder of the BIOM® 5 must be fully pulled out to the stop




Fig. 3–7: Cleaning in an ultrasonic bath

- The products must always be completely submerged in the cleaning solution
- Place the products on trays only
- To ensure the effectiveness of the ultrasonic bath and to prevent damage to the optics, attach the loupes to specially designed holders.



3.6 Steam Sterilisation



Attention


Improper cleaning/disinfection is a health risk.

- After cleaning/disinfecting the components, check whether they are macroscopically clean, i.e. free from visible soiling, corrosion or damage.
- → If impurities are found: Clean/disinfect the components again.
- → If corrosion or damage is found: Do not use corroded or damaged components again for a surgical procedure.


3.6.1 Function Check Prior to Steam Sterilisation

You must check the moving parts of the BIOM® 5 prior to packaging and steam-sterilising them to ensure their function.

- → Check all moving parts of the BIOM® 5.
- Pay particular attention to the following:
 - Smooth movement of the articulated joint
 - Function of the safety rod of the front loupe
 - Function of the focussing knob





→ Flip the BIOM ® 5 towards the adaptor plate. Make sure that the housing body can be shifted without resistance.



Slide the safety rod of the loupe holder up and down several times to check that it runs smoothly. After the test, the rod must be pulled fully down to the stop.







- Check that the knob turns easily and shorten the total length until the adjuster is at the uppermost position.

→ Check whether all fastening screws are present (e.g. screws at the feather key of the safety rod). The control mark (1) must be below the guide.

Fig. 3–8: Test the safety functions



Attention

Risk of injury if components are damaged

- → If a component does not pass the function test, do not use that component for a surgical procedure.
- → Send the components to OCULUS Service or an authorized dealer.

Before sending: Clean, disinfect and sterilise the components. Comply with hospital regulations and all applicable national regulations and laws.



3.6.2 Lubrication

If necessary, you can lubricate the moving parts of the BIOM® 5 prior to steam sterilisation to guarantee their function.

Materials needed

- Lint-free cloth
- Silicone-free maintenance substance which is suitable for the steam sterilisation



Notes

Risk of malfunctions and surface damage if oils containing silicone or other substances are used

Silicone components can solidify during the subsequent sterilisation process (steam sterilisation) and cause the instrument to seize up.

- → Heed the instructions provided with the maintenance oil.
- → Do not use any silicone-based maintenance oils.

If you use substances other than those specified in this manual, you must verify that those substances meet the requirements of DIN EN ISO 17664.




Fig. 3-9: Lubrication

- Lubricate only those locations marked with an arrow.
- → Remove any excess maintenance oil with a lint-free cloth.



3.6.3 Packaging

The sterilisation container (incl. filter material) must meet the following criteria:

- Compliance with the standards DIN EN 868 / ANSI AAMI ISO 11607
- Suitable for steam sterilisation (heat resistant up to 137°C, adequate steam permeability).
- → Prior to sterilisation, place the components in a sterilisation tray and put this into the sterilisation container.

If you use disposable sterilisation packages, these must also meet the criteria specified above.

3.6.4 Steam Sterilisation

Make sure that only cleaned and disinfected components are sterilised.

The optics can be either be double shrink-wrapped or secured in the sterilisation insert from OCULUS Optikgeräte GmbH for autoclaving.

→ Use one of the following sterilisation processes:

Fractionated Pre-Vacuum Process

→ Use a steam steriliser validated according to DIN EN 13060 or DIN EN 285 and DIN EN 17665-1/GOST R ISO 11134 (valid commissioning and product-specific performance evaluation).

The parameters for this process are as follows:

3 Pre-vacuum phases

Sterilisation temperature: 132°CMinimum exposure time: 3 min

Drying time: 1 min

Gravitation Process:

The minimum parameters for this process are as follows:

Sterilisation temperature: 132°C

Minimum exposure time: 15 min

Drying time: 1 min

Adhere to the specified times and temperatures at minimum. Generally speaking, you may exceed the specified times and temperatures. However, longer sterilisation times and higher



temperatures increase the stress on the materials, which could cause them to age prematurely.

The maximum sterilisation temperature is 134° (plus tolerance in acc. with GOST R ISO 11134).



If, for technical reasons, you use other sterilisation processes, shorter sterilisation times and lower temperatures, you must validate these.

4 Storage

→ Comply with hospital regulations and the applicable national regulations and laws for storage of the conditioned products.

5 Disposal

Prior to disposal:

Clean, disinfect and sterilise the components. Comply with hospital regulations and all applicable national regulations and laws.

6 Guarantee and Service

Please note the following guarantee provisions:

- Prior to and while operating the device, it is important that you heed the instruction manual and safety instructions.
- The BIOM® 5 carries a guarantee to which you are entitled in accordance with the legal provisions. This guarantee excludes parts subject to wear, such as the drive module of the BIOM® 5 and the drive belts.
 - The drive module is guaranteed for 100 sterilisation cycles, or max. 6 months from the date of purchase.
- All guarantee claims will be rendered null and void, if:
 - The BIOM® 5 is tampered with by non-authorized persons. Improper modifications and repairs may result in considerable hazards to users and patients.
 - The recommended cleaning, disinfection and sterilisation instructions are not followed.
 - Damage is caused by unauthorized modifications, misuse, or incorrect applications.
- Any transport damage must be reported immediately to the shipping company. Have the transport damage noted on the



- bill of lading so that complaint handling and compensation of damages can proceed in an orderly manner.
- In general, our Business and Shipping Terms applicable on the date of purchase shall apply.

7 Overview: Permitted Sterilisation Method – List of Articles

| | Article No. | | Appro | oved St | erilisation | | | |
|-------------------------------------|----------------|--------------------------|-------------------------|-------------------------|----------------------------------|--|---|---|
| Article Name | | | Steam Autoclave | | STATIM 5000S/G4 | Plasma/ STERRAD® 100S SHORT cycle | Plasma/ STER- RAD® 100NX® Standard cycle | V-Pro® Low Temperatu- re Sterilization System ¹ |
| | | | 134° C (273.2° F) | 132° C (269.6° F) | 134° C (273.2° F); 3,5 min | | | |
| Sterilisation container | 55180 | manual, by machine | Х | Х | | | | |
| Insert for sterili-sation container | 55185 | manual, by machine | Х | Х | | X | Х | Х |
| Insert for sterili-sation container | 55186 | | | | X | X | Х | Х |
| BIOM® 5m | 55462 | manual, by machine | Х | Х | X | х | Х | х |
| BIOM® 5ml | 55463 | manual, by machine | Х | Х | X | х | Х | х |
| BIOM® 5c | 55400 | manual, by machine | Х | Х | Х | Х | Х | Х |
| BIOM® 5cl | 55403 | manual, by machine | Х | Х | Х | X | Х | Х |
| Antriebsriemen BIOM® 5c/cl | 54176 | manual, by machine | х | х | Х | Х | Х | х |
| Cable conduct BIOM® 5 | 54178 | manual, by machine | Х | Х | X | max. 10 times | max. 10 times | Х |



| Adapter | | | | | | | | |
|---------------|--------------|--------------------------|---|---|---|---|---|---|
| Adapter plate | 55423 | manual, by machine | Х | Х | Х | Х | Х | х |
| Adapter plate | 55424 | manual, by machine | Х | Х | Х | Х | Х | Х |
| Adapter plate | 55426 | manual, by machine | х | Х | Х | х | Х | Х |
| Adapter plate | 55431 | manual, by machine | Х | Х | Х | Х | Х | Х |
| Adapter plate | 55425 | manual, by machine | х | Х | Х | X | X | X |
| Adapter | 1000761 7 | manual, by machine | х | Х | Х | х | Х | Х |



| | | | Appro | oved St | erilisation | Processes | | |
|--|---|---|-------------------------|-------------------------|----------------------------------|--|---|---|
| Article Name | Articl e No. | Cleanin g Method | Steam Autoc | | STATIM 5000S/G4 | Plasma/ STERRAD® 100S SHORT cycle | Plasma/ STER- RAD® 100NX® Standard cycle | V-Pro® Low Temperatu- re Sterilization System ¹ |
| | | | 134° C (273.2° F) | 132° C (269.6° F) | 134° C (273.2° F); 3,5 min | | | |
| Adaptor Accessorie | es | | | | | | | |
| Sterile cap for knurled screw | 54580 | manual | х | х | х | X | Х | Х |
| SDI | | | | | | | | |
| SDI® II e SDI® II m SDI® 3 c SDI® 4m SDI® 4e SDI® 4c | 54800 54802 54805 54810 54812 54815 54820 54830 54302 54305 54310 54312 54315 54320 54330 54331 54332 | Sterilisatio n not possible Wipe disinfectio n permitted, as for surgical microscop e | | | | | | |
| Rubber cap for SDI® II, SDI® 3 and SDI® 4 star knob | 54335 | manual, by machine | Х | Х | X | X | | |



| | | | Appro | oved St | erilisa | tion | Processes | | |
|---|------------------|-----------------------|-------------------------|-------------------------|-----------------------|------|--|---|---|
| Article Name | Articl e No. | Cleaning Method | Steam Autoc | | STA 5000 | | Plasma/ STERRAD® 100S SHORT cycle | Plasma/ STER- RAD® 100NX® Standard cycle | V-Pro® Low Temperatu- re Sterilization System ¹ |
| | | | 134° C (273.2° F) | 132° C (269.6° F) | 134° C F; 3,5 i |); | | | |
| Reduction Lenses | ' | | | | | | | | |
| Reduction lens for f = 175 mm on BIOM® 5m/c | 55401 | manual, by machine | Х | Х | Х | Х | X | х | X |
| Reduction lens for f=200 on BIOM® 5ml/cl | 55404 | manual, by machine | Х | Х | х | Х | X | х | X |
| Reduction lens for f=200 on BIOM® 5m/c | 55405 | manual, by machine | Х | х | Х | Х | X | х | Х |
| Front Lenses for BIC | M [®] 5 | | | | | | | | |
| Hi-res macula lens | 53606 | manual, by machine | Х | х | Х | Х | Х | Х | Х |
| WiFi-HD mini lens | 53605 | manual, by machine | Х | Х | Х | Х | Х | X | Х |
| 90 D lens | 53604 | manual, by machine | Х | Х | Х | Х | Х | Х | Х |
| WiFi-HD lens | 53603 | manual, by machine | Х | Х | Х | Х | Х | X | Х |
| Wide-field lens | 53602 | manual, by machine | Х | Х | Х | Х | Х | X | Х |
| Mini Wide-Field lens | 53601 | manual, by machine | Х | X | Х | X | X | Х | Х |



¹ tested V-Pro® systems (sterilizing agent VAPROX® HC):

V-Pro® 1 Low Temperature Sterilization System

V-Pro® 1 Plus Low Temperature Sterilization System

V-Pro® 1 maX Low Temperature Sterilization System

V-Pro® 60 Low Temperature Sterilization System

8 Consumables and Sterilisable Accessories

| Article number | Designation |
|--------------------|--|
| 54335 | Sterilisable rubber cap for SDI® II, SDI® 3 and SDI® 4 (pack of 5) |
| 54580 | Sterilisable cap for knurled screw (pack of 5) |
| 54176 | Sterilisable drive belt (pack of 10) |
| 54178 | Cable duct for BIOM® 5c (pack of 5) |
| 55180 | Sterilisation container with insert for BIOM ® 5 and accessories |
| 55185 | Insert for the sterilisation container for BIOM® 5 |
| 54187 | Loupe washing holder |
| 55190 | Paper filters for sterilisation container (100 pcs/box) |
| 01 54538 01 002 | Knurled screw M3 for dovetail mount 54511, 54537, 54538, 54552, 54622,54623, 54121, 54142, 54144, 54622 01 000, 54623 01 000, 54552 01 000 |
| 546391 | Set of knurled screws (pack of 2) for intermediate plate for Möller microscope |



Attention

Personal injury caused by contaminated BIOM® and components

→ Before returning the product to OCULUS: Prepare the BIOM® and sterilisable components according to this treatment instructions.



→ Send only visibly prepared OCULUS products back to OCULUS

9 Appendix

| Product | All models and accessories of the BIOM® 5. You will find an itemized list in the Conditioning Instructions BIOM® 5 | | | | | |
|---|--|--|--|--|--|--|
| Notes | This guide is only intended to help you with the cleaning, disinfection and sterilisation process. For more detailed information, please refer to the Conditioning Instructions for the BIOM® 5 | Other sterilisation methods must be validated by the user. Clean or disinfect the BIOM[®] 5 by machine, as this is much more effective. | | | | |
| Process Instructions | Due to the design of the product and the materials used, a definite limit of the maximum number of conditioning cycles that can be performed cannot be given. The serviceable life of the products depends on their function and the care with which they are handled. | Faulty Products Before sending: Clean, disinfect and sterilise the components. Comply with hospital regulations and all applicable national regulations and laws. Send the components to OCULUS Service or an authorized dealer. | | | | |
| Decontamination Preparations | No special measures necessary | | | | | |
| Preparations at the Site of Use | Detach the BIOM ® 5 from the microscope | · | | | | |
| Preparations at in the conditioning station | Dismantle the BIOM ® 5 | | | | | |
| Transport and Storage | Safe storage in a closed container and transport of the products to the conditioning location | | | | | |
| Pre-Cleaning | Material: Cold water, water pistol Procedure: Place the BIOM® 5 in cold water for five minutes. The BIOM® 5 must be fully covered. Flush out gaps, joints and cavities (the marked locations) for fifteen seconds with the water pistol. | | | | | |

| Cleaning/Disinfection | Cleaning/disinfection by machine | Manual cleaning/disinfection |
|-----------------------|---|--|
| Cleaning/Disinfection | Cleaning/disinfection by machine Material: CDU (with therm. disinfection programme, 5 minutes at 90°C, for A ₀ value=3000), detergent CDU, cold water, demineralised water Procedure: 3 Minute pre-wash cycle with cold water Empty 5 Minute cleaning cycle at 55°C with neodisher MediClean (concentration 0.5%, Dr. Weigert, Hamburg) Empty 3 Minute rinse cycle with cold, demineralised water | Manual cleaning/disinfection Material: Cleaning solution with 0.8% detergent (Cidezyme/Enzol from Johnson & Johnson), water Procedure: Check that the components have no visible signs of soiling. Place the components in the cleaning solution for 5 minutes at 40°C. The BIOM® 5 must be fully covered. Rinse the components for 5 seconds under running water (static pressure 4.2 bar). Optional: Clean in an ultrasonic bath |
| | Empty 2 Minute rinse cycle with demineralised water Empty Check whether the BIOM[®] 5 needs to be dried off with compressed air | |

| Functional test: | Check | | | | | | |
|---|---|--|--|--|--|--|--|
| | Smooth movement of the articulated joint Function of the safety rod of the front loupe. After conducting this check, the control mark must be at position (1) | | | | | | |
| | | | | | | | |
| | Function of the focussing knob | | | | | | |
| | whether all fastening screws are present | | | | | | |
| Transport | Pack the products or the sterilisation tray with the components in accordance with standards DIN EN 868 / ANSI AAMI ISO 11607 | | | | | | |
| Sterilising | Fractionated Pre-Vacuum Process | Gravitation Process: | | | | | |
| | Material: Validated steam steriliser, in acc. with DIN EN 13060 or DIN EN 285 and DIN EN 17665-1/GOST R ISO 11134 Parameters: 3 Pre-vacuum phases Sterilisation temperature: 132°C Minimum exposure time: 3 min Drying time: 1 min | Minimum Parameters: Sterilisation temperature: 132°C Minimum exposure time: 15 min Drying time: 1 min The maximum sterilisation temperature is 134° (plus tolerance in acc. with GOST R ISO 11134. | | | | | |
| Devices and substances validated in studies | Laboratory Washer: Miele G 7735 CD | Detergent: neodisher MediClean (concentration 0.5%, Dr Weigert, Hamburg | | | | | |

WWW.OCULUS.DE



Münchholzhäuser Str. 29 \cdot 35582 Wetzlar \cdot GERMANY Phone +49 641 2005-0 \cdot Fax +49 641 2005-255 E-mail: sales@oculus.de \cdot www.oculus.de



